


HOW TO REGISTER A LUX INVERTER

1. Make Sure you have your dongle on hand.



2. Go to: <https://server.luxpowertek.com/> or download the App “LuxPowerView” on your smartphone, Click on “Register”



3. Make sure you are on the North america server. Create an username and a password easy to remember. Use an email address that you have access to.

* Cluster (?)	<input type="text" value="North America"/>	▼
* Username	<input type="text" value="Any User Name"/>	✓
* Password	<input type="password" value="....."/>	✓
* Repeat password	<input type="password" value="....."/>	✓
Nickname	<input type="text" value="Any Nickname"/>	
* E-mail	<input type="text" value="m.smith@gmail.com"/>	✓
Tel number	<input type="text" value="Tel number"/>	

4. Name your station so you can remember it. Select if you want daylight saving time or not. Choose the Continent “North America”, Region “North America” and Country “United States of America”. Select the Timezone of your choice.

* Station name ✓

* Daylight saving time Yes No

* Continent ▼

* Region ▼

* Country ▼

* Timezone ▼

Address

5. Type the Customer Code “BBD0001” if you are an end user that purchased the inverter from BigBattery and you want to monitor your Inverter. If you are an Installer, type the solar installer code provided by BigBattery or by one of our distributors. If you are a solar installer and you want a Customer Code, please contact support@bigbattery.com to request your code, or contact the distributor where you purchased your system.

* Customer code ✓

6. Type the Dongle SN and PIN that are located on the dongle you received.
Click on Register.

* Dongle SN

* Dongle PIN

Register

Back to login page